



# Linksys BEFW11S4 Teardown

Written By: William



## INTRODUCTION

This wireless router stopped working, so I wanted to take a look at it's innards.

---

### TOOLS:

- [Phillips #1 Screwdriver](#) (1)
  - [Spudger](#) (1)
  - [Smart Wrench](#) (1)
-

## Step 1 — Linksys BEFW11S4 Teardown



- Waiting to be disassembled...

## Step 2



- Remove antennas.
- Remove nuts and washers around antenna connectors.
- Push in antenna connectors.




## Step 3




- Remove feet (with flat-head screwdriver, fingernails, etc).
- Unscrew the screws.

## Step 4






- Pull apart blue front from black back with a LOT of force.
- Slide and pull up bottom. (Make sure the antenna connectors get through.)

## Step 5





- Twist and pull out antenna connector feeds.


## Step 6



- Pull up RF shield from motherboard.
- Unscrew the motherboard from the bottom.
- Push the motherboard forward (as in this picture) to unlatch it from the bottom.

## Step 7




 Some people have a card where you have to unscrew it. If that is your case, do that. The instructions below is for my type of router.

- Push the card forward to deattach the pins.
- Remove the card from the metal holdster.




## Step 8



- Here are the markings on the motherboard chips. If you have any info on these chips, please comment!
- Macronix 29F040QC-90
- ISSI IS41C16100S-50K
- SAMSUNG ARM S3C4510X01-QERO
- RMC RTL8019AS
- Bothhands FB2022
- Bothhands 40ST1041E
- Kendin KS8995. Kendin has since been bought by Micrel.

## Step 9



- Enjoy!

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 05:36:28 PM.